



Robotic Inspection of Complex Structures Ian Cooper

Acknowledgements – The Intacom Team Martyn Lindop, Nathan Hartley, David Carswell and Jonathan Riise

Materials Joining and Engineering Technologies



IntACom Programme





New Robot Cell

Tracks 10m

Turntable 4m Dia

Parts:

14m Long

5m High











Managing Large Data Sets

- Limit sub-paths (coordinate indexes) to 1m in x and y
- Acquire every mm, but plot every 100 mm
- Use multiple coordinate files targeting same data
- Only allow loading of 1 (or 2) high res sub-regions



Exaggerated here (screen is 1080p while mesh will be at much higher density)



Laser Profiler Integration

Software developments: laser integration in IntACom 2







Software Integration

- High accuracy, automated calibration of component position
- Ability to generate surface point clouds
- Automated TCP calibration procedure (ca. 0.3mm error)

	٩		Solid ~ OFF II Path 1 Acquisition
	• • [#]		
Configuration			
Inspection Types	Treaugh L. +		
Device ID:	101.1.3	CALIBRATION	□ 185.0 40.115 PATH (IVHO) ● CADA (2011) ★ VELOCITY (INA) 185.0 2800 000
Sample Rate (MHz):	50 💌	A CONTRACTOR OF A CONTRACTOR OFTA CONTRACTOR O	₩ 155.0 ¥ 34.0 ¥ 2800.000
Pitch:	0.75	Dischamer	Cytian Lase unity +
Num Elements	21	Laser Calibration	
Use Elements:	1-21		
Use Sub-Aperture:	M.		
Aperture Size:	7		Dwore acception TROL 2859-30 (42-14
Increment:	2		
Reverse Flements:	V.		Resolution C +
Reverse Slave Elements:	1		fleduced power
Inspection Settings			
Scan Increment:	1.5		
Left	-5.25		
Right	5.25		
Тара	0.0		
Bottom:	70.0		
Velocity:	2800.0		
Water Path:	155.0		
Water Velocity	1490.0		
Averages:	1 •		Laser Off Store Mt Calculate Acquire Coulfrin
Maximum Scan Speed:	0		
CAD			
CAD File:	cad.stl 🗂		
Rotate X:	88.615079355		
Rotate V:	88.676913213		
Rotate Z:	144.34645811		
Translate X:	-91,692611694		
Franslate Y:	-37.295368957		
Tenerinto T	The strengt and the		





Motion Capture Technology

Mainly used in animation, medical and sports science for tracking humans (or animals!)

Passive markers are tracked by arrangement of cameras to provide 3D position as well as orientation

Use of Qualisys system for tracking robots and for encoding of on-site scanning



Image credits: Thanya Nualla-ong (https://www.coroflot.com/thanya919/portfolio)



Use Cases

- Robot tracking
 - Component position tracking
 - Track robots for path corrections
 - Track cooperating robots
 simultaneously
 - Encode data at high feedback rates
- On-Site Scanning System
 - Track hand-held probes in 3D
 - Manually scanning curved surfaces
 - Interface with IntACOM software to overlay data on CAD
 - Ability to visualise scans from different areas together







Motion Capture at TWI

- 8 Qualisys cameras installed on lightweight scaffold
 - Can be set up on tripods instead
- Line of sight required to markers from at least 2 cameras
- Tracking volume up to 10s of m³, depending on camera placement







Tracking System

- Covered volume can be checked in software
- Define rigid body to get 6DoF information
- Track up to 1000s of markers at same time
- Resolution of 0.02mm





Tool Holder

Attach at least 3 markers to probe Initial design created for a 5MHz, 64 element probe Use CAD to find transform between ref frames





Tracking Results

Curved surface





Site Inspections

IntACOM partner RNLI seeking solution for large area inspection on site Use of cameras to track probe movements on boat hull Site trials conducted to determine feasibility and accuracy



Software Interface during Scan



TWI



3D C-Scan of Reference Plate





Comparison with OmniScan





OmniScan Manual PA

Qualisys/IntACom

Missing areas: poor reflectivity and high tolerance for triangulation



Original nozzle design



Design created during Intacom 1

Elements



Improved nozzle design 1st Iteration



All element responses were within a 3dB threshold of each other



Improved nozzle design 2nd Iteration



Achieving better consistency across the array





Test A

 $N:\Projects\25nn\25692\Misc\Swansea Student 4th Year MEng Project 2018-2019\Testing 20-21 Feb 2019_Videos\Test 10$



Questions?



Thank you for listening Ian.Cooper@twi.co.uk +44 (0)1639 873100 Mob +44 (0)7557 002335